



## How To Program Your Amino Remote Control With Auto Search

**Notice:** this process may take a long time to find your TV code (in cases up to 5 minutes). Make sure your TV set is turned on. (The set-top box does not need to be turned on to perform this programming feature).

1. Press and hold both the 1 and the 3 buttons at the same time on the remote control for approximately 3 seconds until the TV standby button remains lit, then release both buttons.
2. Point the remote control at the TV set and press and hold down the TV Standby button or the Mute button on the remote control.
3. When the TV either turns off or brings up the MUTE symbol on screen, release the button. This may take up to 5 minutes to happen.
4. Press and hold the Text/SHIFT button and then at the same time press the STOP button to finish setting up the TV control mode. The TV standby button will go out. The TV control function is now programmed into the remote control.

If the TV brand is not successfully found by the remote control, the TV standby button will flash rapidly and the remote control will revert to normal operation. No TV brand code will be stored. If Auto Search also fails to successfully setup operation of the TV set, the remote cannot be used to control this particular TV set.

**For additional programming methods and manufacturer Brand codes please visit: [KTC.net/support](http://KTC.net/support)**